



Geometris 8x Series

Installation Guide



J-Bus Adapter For Heavy-Duty



OBD-II Y Cable For Light-Duty

Our plug-in device works in most light-duty and medium-duty vehicles made after 1995 and instantly plugs into the OBD-II port on your vehicle. This unit can be used for ELD tracking with a Bluetooth connection to the tablet or phone being used for Driver App access. Enabling ELD will require an additional monthly fee per unit. Please contact our Sales Team for pricing details.

Installation

To install your 8x Series Geometris units, fit the device into the OBD II port of your vehicle. To locate the OBD II port, consult the User Manual for your vehicle. When installing the device, ensure that the vehicle is outdoors with a clear view of the sky (no metal roofs or overhangs). The device should report within a few minutes of installation. Turning on the engine can help the unit report sooner. If the device has been installed for longer than 1 hour without a response, please contact our Support Team for assistance.

Y Cable Install For Light-Duty Vehicles



The OBD-II Y Cable adapter for light-duty vehicles helps ensure the Plug-In Device is always connected to the vehicle's OBD-II port. This adapter has enough cabling to reposition the GPS tracker out of view while maintaining an additional accessible OBD-II port in the vehicle.

J-Bus Cable For Heavy-Duty Vehicles



The J-Bus Y Cable adapter for Heavy-Duty Vehicles helps ensure the Plug-In Device is always connected to the vehicle's J-Bus port. This adapter has enough cabling to reposition the GPS tracker out of view while maintaining an additional accessible J-Bus port in the vehicle.

Troubleshooting - Device is Not Reporting (Offline)

If your Plug-In device has not reported in over 1 hour, it is most likely not connected to a mobile network. If the device is in a remote area, then it should regain connection once it re-enters a mobile coverage zone. If the device does not report for an extended period, this could be a result of device malfunction or the device could have come unplugged for some reason.

If you have access to the vehicle, we recommend that you check to see if it is still plugged in. If it is, are the green and orange LEDs on? If there are no LEDs on, it could mean that a fuse has blown in the vehicle, and you could try plugging the device into another vehicle. If the LEDs do not come on when plugged into another vehicle or the orange LED does not stop blinking after a few minutes, please contact our Support team, and we will resolve this issue. The green and orange LEDs are on the side and may be faint/hard to see.



Download the Zonar App



Scan QR for Apple iOS Devices



Scan QR for Google Devices

If you are new to Zonar, make sure to check your email inbox for an email from emailverification@fleetsimplified.com confirming your login credentials.

 **Phone**
866-261-8571

 **Support**
24 hours a day, 7 days a week

 **E-Mail**
customercare@zonarsystems.com

Zonar systems and affiliate entities provide installation guides for their GPS tracking devices. Incorrect handling and installation of GPS tracking devices could result in damage to the vehicle, the device, or the installer. Zonar systems and affiliate entities hereby disclaim any and all liability for all damages, losses, expenses, and costs occurring as the result of (or in association with) the installation of these devices by the customer or others.